


Packing & Unpacking



PictureCube Extrusions






Table Top




Corner Connectors




Light Assembly

Standard Table Kits


23" Table
23" x 23" x 40"




46" Table
46" x 23" x 40"




69" Table
69" x 23" x 40"




Assembly




Foot Assembly




Corner Connector



Straight Connector



Internal Light



Fabric Panel

1. Start at the upper corner of the assembly by pressing the edge of the panel into the extrusion. Work the panel edge into the entire length of the upper extrusion.
2. Work the panel edge into each of the side extrusions about 1/3 the way down.
3. Work the panel edge into the entire length of the lower extrusion.
4. Work the panel edge into each of the side extrusions about the rest of the way down.
5. Repeat for each side the PictureCube Table.

